

Skyline Type Foundry Font Schemes Chart

C A P I T A L S	E	4	5	6	8	9	10	11	12	13	14	17	18	19	21	22	23	24	27	30
	A I N O R S T	3	4	5	6	7	8	9	10	11	12	14	15	16	17	18	19	20	22	25
	C L	2	3	4	4	5	5	6	7	7	8	9	10	11	12	12	13	13	15	17
	D H M P U	2	2	3	4	4	5	5	6	7	7	8	8	9	10	10	11	11	12	13
	F G	2	2	3	3	3	4	4	5	5	6	7	7	8	8	9	9	9	10	12
	B W Y	2	2	2	3	3	3	4	4	4	5	6	6	7	7	8	8	8	9	10
	J K V	2	2	2	2	3	3	3	4	4	4	5	5	5	5	6	6	6	7	7
	Q X Z & \$	2	2	2	2	2	2	3	3	3	3	3	3	4	4	4	4	4	5	5

L O W E R C A S E	e	8	10	12	13	14	19	21	24	27	37	43	48	53	59	60	67	73
	a i n o r s t	6	8	9	10	11	14	16	18	20	28	32	36	40	44	45	50	55
	h l	4	5	6	7	8	9	11	12	13	19	21	24	27	29	30	33	37
	d	4	5	6	7	8	9	10	11	12	17	19	22	24	26	27	30	33
	c f m u . ,	4	5	5	6	6	8	9	10	11	15	17	19	21	23	24	27	29
	b g p w y	3	3	4	4	5	6	7	8	8	11	13	15	16	17	18	20	22
	j k v - ' 	2	3	3	4	4	5	5	6	6	8	9	9	10	10	11	12	13
	q x z ; : ! ?	2	2	2	3	3	3	4	4	4	5	6	6	7	7	7	8	9
	f i f f	1	1	1	2	2	3	3	4	4	5	5	5	5	5	6	6	6
f l f f i f f l	1	1	1	2	2	2	2	3	3	3	3	3	3	3	4	4	4	
Quantities of the respective characters may be reduced if ligatures are furnished.																		

F I G S	0	4	5	6	7	8	10	12	13	15	17
	1	3	4	5	6	7	8	10	11	12	13
	2 3 4 5 6 7 8 9	3	3	4	4	5	6	8	9	10	11

How To Read This Chart

Every type font has an "A-Count" (for example, 14-A 28-a 8-1). In the Capitals block, on the line containing A, find the box for 14, and read the quantities of all capitals in this column. Likewise with Lowercase and Figures in their respective blocks. "Title Fonts" have no lowercase.